



## KOMPLETI ZA NADOGRADNJU

### ZA PROMENLJIVE PROTOKE VAZDUHA ILI V<SUB>MIN</SUB>-V<SUB>MAKS</SUB> PREBACIVANJE U SISTEMIMA ZA KLIMATIZACIJU PROSTORIJE

Pokretači i pribor za ugradnju za mehaničke automatske regulatore konstantnog protoka vazduha tip EN, RN, ili VFC, kao i za prigušne klapne tipa VFR

- Kompleti delova za jednostavnu nadogradnju
- Potencijometar ili mehanički graničnici
- Radni napon 24 V AC/DC ili 230 V AC
- Ulazni komandni signal: naponski signal 0 - 10 V DC za varijabilne pokretače
- Ulazni komandni signal: 1-žična regulacija ili 2-žična regulacija (3-tačke) za min/maks prebacivanje
- Usko naleganje na regulator konstantnog protoka vazduha ili prigušnu klapnu

Opcionalni pribor za tip RN i EN

- Pomoćni prekidač sa podesivim uklopnim tačkama, na primer za detekciju krajnjeg položaja

## Primena



### Primena

Kompleti delova za nadogradnju mehaničkih automatskih regulatora zapreminskog protoka vazduha ili prigušnih klapni sa pokretačima

Regulatori konstantnog protoka vazduha tip EN ili RN, kao i za VFC

- Min/Maks prebacivanje zadatih vrednosti zapreminskog protoka
- Varijabilno podešavanje zadatih vrednosti zapreminskog protoka

Za prigušne klapne tipa VFR

- Min/Maks promena položaja regulacione klapne

## Opis



### Delovi i karakteristike

- Regulaciona klapna može da zauzme različite položaje
- Mehanički graničnici ili potenciometri (samo za tipove VFC ili VFR) se koriste za podešavanje zapreminskog protoka
- Radni napon 24 V AC/DC ili 230 V AC
- Prebacivanje između zadatih vrednosti ili opseg naponskog signala 0 - 10 V DC

## TEHNIČKE INFORMACIJE

### Actuators for volume flow controllers Type RN or EN

Part number	Quality	Supply voltage	Model	Identical to attachment
NR-VAV-B50	Min/Max switching, mechanical stops	24 V AC/DC	LMA24-F	B50
NR-VAV-B60	Min/Max switching, mechanical stops	230 V AC	LMA230-F	B60
NR-VAV-B70	Variable adjustment, mechanical stops	24 V AC/DC	LMA24-SR-F	B70
NR-VAV-S2	Auxiliary switch		S2A	B*2
NR-VAV-RNMAT	Installation accessories for RN			
NR-VAV-ENMAT	Installation accessories for EN			

Installation accessories for CAV controllers Type EN or RN are to be ordered separately

Retrofit kits for EN, RN, VFC, VFR

NR-VAV-B50



**Retrofit kit**

For Types RN and EN

- NR-VAV-B50** Retrofit actuator for min/max switching, identical to attachment B50
- NR-VAV-B60** Retrofit actuator for min/max switching, identical to attachment B60
- NR-VAV-B70** Retrofit actuator for variable adjustment, identical to attachment B70
- NR-VAV-S2** Retrofit auxiliary switch, identical to attachment B\*2

**NR-VAV-RNMAT** Installation accessories for RN

**NR-VAV-ENMAT** Installation accessories for EN

For Types VFC and VFR

- NR-VAV-E01** Retrofit actuator for min/max switching, identical to attachment E01
- NR-VAV-E02** Retrofit actuator for min/max switching, identical to attachment E02
- NR-VAV-E03** Retrofit actuator for variable adjustment, identical to attachment E03
- NR-VAV-M01** Retrofit actuator for min/max switching, identical to attachment M01
- NR-VAV-M02** Retrofit actuator for min/max switching, identical to attachment M02